
user manual quide de l'utilisateur manual de usuario

Thank you for purchasing an 808 product. We pride ourselves on the quality and reliability of all our electronic products, but if you ever need service or have a question our customer service staff stands ready to help. Contact us at www.808audio.com. PURCHÁSE **REGISTRATION:** Registering Online will allow us to contact you in the unlikely event a safety notification is required und Federal Consumer Safety Act. Register Online at: www.808audio.com. Click on Product Registration and Fill Out the Brief

Enregisregistro del productotrement du produit

Gracias por comprar un producto 808. Nos enorquilece la calidad y fiabilidad de todos nuestros productos electrónicos, pero si alguna vez necesita servicios técnicos o si tiene alguna pregunta nuestro personal de atención al cliente está a su disposición para ayudarle. Comuníquese con nosotros en www.808audio.com. **REGISTRO DE COMPRA:** El registro en línea nos permitirá comunicarnos con usted en el caso de tener que enviarle algún aviso de seguridad en virtud de la Ley Federal de Seguridad del Consumidor. **Registre el producto en línea en: www.808audio.com. Haga clic en Registro del producto y responda al** 



Enregistrement du produit

Merci d'avoir acheté un produit 808. Nous sommes fiers de la qualité et de la fiabilité de tous nos produits électroniques, mais en cas de nécessité de réparation ou pour toute question le personnel de notre service clientèle est prêt à vous aider. Contactez-nous sur www.808audio.com. ENREGISTREMENT D'ACHAT: Enregistrer votre produit en ligne nous permettra de communiquer avec vous pour tout avis de sécurité au sujet du produit en vertu du Federal Consumer Safety Act (Loi fédérale de protection du consommateur). Enregistrez votre produit en ligne sur: www.808audio.com. Cliquez sur Enregistrement produit et remplissez le court questionnaire.

It is important to read this user manual prior to using your new product for the first time

Es importante leer este manual antes de usar por vez primera su equipo Nous vous recommandons de lire ce manuel d'instructions avant d'utiliser votre nouveau produit nour la première fois



## Regulatory Information

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions (1) This device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired

### RF Exposure Warning

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and transmitter operating conditions for

satisfying RF exposure compliance.

## Industry Canada Regulatory

condition

Industry Canada

operation of the device.

Regulatory Information

Canada license-exempt RSS standard(s).

two conditions: (1) this device may not

must accept any interference, including

interference that may cause undesired

The user is cautioned that this device

should be used only as specified within

requirements. Use of this device in a

manner inconsistent with this manual

this manual to meet RF exposure

Operation is subject to the following

cause interference, and (2) this device

This device complies with Industry

Information CAN ICES-3 (B)/NMB-3 (B) Avis d'Industrie Canada CAN ICES-3 (B)/NMB-3 (B)

## **Specification**

### **Electrical power information** AC/DC adapter

Input: 100-240V ~ 50-60Hz Output: 5V === 1.2A

### Bluetooth version 3.0 FDR

Supported Bluetooth Profiles: A2DP 1.0 (Advanced Audio

 AVRCP (Audio / Video Remote Control Profile) v1.0

### Operating Range

could lead to excessive RF exposure Frequency

### Music playing time (maximum

- Bluetooth Compliance:

## Distribution Profile

10 meters Bluetooth standard

## 2 4 GHz

### **Battery and Battery Life:** Accessories :

**Enalish** 

CAUTION

SEE MARKING ON BOTTOM / BACK OF PRODUC

Some of the following information may

nowever, as with any electronic product.

precautions should be observed during

not apply to your particular product;

WARNING: TO PREVENT FIRE OR

THIS PRODUCT TO RAIN OR MOISTURE

handling and use.

Read these instructions

Keep these instructions

Follow all instructions.

· Clean only with dry cloth.

Do not use this apparatus near

The Bluetooth® word mark and logos

are registered trademarks owned by

is under license. Other trademarks

and trade names are those of their

respective owners

Bluetooth SIG. Inc. and any use of such

marks by VOXX Accessories Corporation

Heed all warnings.

ERTING YOU OF NGEROUS BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR WARNING SIGN

- 3.5 mm stereo iack cable Battery type: Lithium Ion battery Micro USB cable
- AC/DC adapter volume level) : 5 hours

SP920-A

- · Music playing time (medium volume): 10 hours
- Charging time: 2.5 hours

### **Audio Features**:

- Compatible with any Bluetooth A2DP phone, PC, laptop, tablet or mp3 plaver
  - · 3.5mm auxiliary input jack for non Bluetooth A2DP mp3 players, smartphones, or computers

### Size and Weight:

- Height: 107 mm Width: 273 mm
- Depth : 83 mm Weight: 1.4 lbs

## Introduction

The SP920 is a portable, wireless stereo speaker featuring a portable design and compact footprint.

Do not block any ventilation

openings. Install in accordance with

Do not install near any heat sources

stoves, or other apparatus (including

Portable Cart Warning

the manufacturer's instructions

such as radiators, heat registers,

apparatus. When a cart is used,

apparatus combination to avoid

Unplug this apparatus during

Refer all servicing to qualified

service personnel. Servicing is

required when the apparatus has

been damaged in any way, such

use caution when moving the cart/

lightning storms or when unused for

amplifiers) that produce heat.

Use only with the

bracket, or table

specified by the

or sold with the

injury from tip-over

long periods of time.

manufacturer,

cart, stand, tripod,

Users can stream music wirelessly from any cell phone, tablet, computer, laptop or mp3 player supporting Bluetooth AVRCP or A2DP

The integrated rechargeable battery ensures 5 hours of non-stop, maximum volume music, and up to 10 hours of moderately played melodies.

The SP920 comes with a 3.5 mm stereo iack cable for devices that do not support Bluetooth AVRCP or A2DP

## Charging

dropped.

### Plugging in for power

Connect the supplied power adapter to the DC IN jack on the back of the SP920, and connect the other end to a convenient wall outlet.

The charge indicator of the SP920 will turn solid red while the speaker is charging. It turns solid green when the speaker is fully charged.

**IMPORTANT SAFETY INSTRUCTIONS** 

product

components

from the mains

place product in or on a bed rug

may prevent air flow through vent

Care should be taken so that objects

or in a bookcase or cabinet that

Do not place lighted candles,

cigarettes, cigars, etc. on the

do not fall into the product.

Do not attempt to disassemble

the cabinet. This product does

not contain customer serviceable

· The marking information is located

To be completely disconnect the

The ventilation should not be

openings with items such as

No naked flame sources such as

at the bottom panel of apparatus.

power input, the AC/DC adapter

of apparatus shall be disconnected

impeded by covering the ventilation

newspaper, table-cloths, curtains etc.

as power-supply cord or plug is

or objects have fallen into the

damaged, liquid has been spilled

apparatus, the apparatus has been

exposed to rain or moisture, does

not operate normally, or has been

ADDITIONAL SAFETY INFORMATION

The AC/DC adapter supplied with

correctly oriented in a vertical or

Do not use unauthorized chargers

chargers or power adapters that

came with your product or that is

Apparatus shall not be exposed to

filled with liquids, such as vases,

should be placed on the apparatus.

Always leave sufficient space around

the product for ventilation. Do not

dripping or splashing and no objects

or power adapters. Use only

listed in the user's guide.

this product is intended to be

floor mount position.

When the battery is low, the charge and pairing indicators will begin to blink slowly.

### The battery should be fully charged prior to first use.

Once the battery is fully discharged, immediately recharge (regardless of wether you plan to use battery or not) in order to maximize battery time. If you plan not to use the battery for an extended period of time (one week or longer), we recommend that you fully charge the battery. For longer periods of storage, please recharge the battery at least once every two months to maintain the battery in optimum condition.

# Turning On/Off

Power On: Press the () button at the back of the SP920. A power on beep tone will be heard and the Pair indicator will blink

back of the SP920


and hold the Volume + and Volume buttons simultaneously; the speaker will turn off. Press the () button to turn the speaker back on.

### General controls

Rear view

## General controls

qualified personnel.



Right view

Power Off: Press the () button at the

lighted candles should be placed on

Only use this in moderate climates

battery and charging system which is

designed to work in temperatures that

do not exceed 50°C (122°F). Leaving

this product in a closed automobile

or the trunk of an automobile where

temperatures may exceed 50°C may

result in permanent battery damage.

fire, or explosion. Please remove your

product from the automobile when

you exit, do not place your product in

the trunk of your automobile, and do

not leave your product in any location

where temperatures may exceed 50°C.

Your product must be disposed of

regulations. Because this product

properly according to local laws and

Important battery information

Warning: Your product contains a

the apparatus



# Left view

**(9** 

contains a battery, the product must

be disposed of separately from the

Do not use the unit immediately

after transportation from a cold

Do not store the unit near fire,

place to a warm place; condensation

places with high temperature or in

direct sunlight. Exposure to direct

sunlight or extreme heat (such as

inside a parked car) may cause

. Clean the unit with a soft cloth or

· The unit must only be opened by

a damp chamois leather. Never use

damage or malfunction.


household waste

solvents

Precautions for the unit

problems may result.

Reset the Speaker: On the speaker, press



(1) AUX IN Line level input jack for analog

(2) DC IN

Micro USB input jack for recharging the speaker.

audio playback

### (3) Charge indicator

Solid red Charging Flashing red Low battery, charging is Solid green Battery full USB charger is **Pairing indicator** 

Very slow

flash in blue

Solid blue

blue

Fast flash in Ready for pairing

In Standby mode

Reconnecting to the

Rluetooth connection

stablished

Flashing red Low battery, charging is

most recently connected

different device, press and hold for 3 seconds to break the curren connection and initiate pairing.

speaker. You may also need to

## Solid white AUX input connected

(4) Skip forward button Press and hold to fast forward within the current track.

For Canada Customers, please ship to Audiovox Return Centre c/o Genco 6685 Kennedy Road Unit#3, Door 14, Mississuaga, Ontario L5T 3A5

## Pairing

Pair the SP920 with your phone/device to create an audio streaming link between the two devices. Your devices must be paired before music can be played.

mportant : Make sure that your phone/device supports Bluetooth A2DP\* (Advanced Audio Distribution Profile) before proceeding. \*A2DP (Advanced Audio Distribution Profile) is a technology enabling to stream stereo sound from an audio source (phone, PC. laptop, tablet. mp3 player) to a stereo speaker or headset via Bluetooth. To do so, both devices must

support this profile.

1. If the SP920 is off, press the () button to turn it on 2. If this is the first time you are turning on SP920, the Pair indicator blinks in blue rapidly. This indicates that SP920 is ready to be paired. If the Pair indicator does not blink rapidly, press and hold the Pair

While the SP920 is in pairing mode, select 808 Hex XL from the list of Bluetooth devices of your phone

button for 3 seconds.

4. If your phone asks for a password/ pin code, enter 0000 and press OK. Upon successful pairing, the SP920

use with your phone.

will beep once. It is now ready to

you come back into the Bluetooth

## Reconnecting

When you turn it on, the SP920 reconnects automatically with the last paired device. When you leave the Bluetooth operating range, with the SP920 turned ON, it disconnects. When operating range, press the Pair button to reconnect to the last paired device. The SP920 will beep once it has been successfully repaired.

Important: The SP920 needs to be paired with vour Bluetooth A2DP phone/device before you can stream music to the speaker. for details on how to pair with the SP920.

> 1. Go to your phone's music player and play a track by pressing "Play" . If the SP920 is connected, the music

## Streaming music

Please refer to the Pairing section

See your phone's manual if needed. 2. To adjust the volume of your

audio: Use the - and + buttons of

the speaker. You can also use the

volume controls on your phone.

## Auxiliary source

will be heard directly in the speaker

player directly.

Aux In and the other end into the output of your music player. . Press "Play" on your music player to

## stream music directly via the SP920 and use the controls on your music

### 1. Plug one end of the supplied 12 Month Limited Warranty Applies 3.5 mm stereo jack cable into the to 808 Audio Products

To obtain repair or replacement within the terms of this Warranty, the product is to be delivered with proof of warranty coverage (e.g. dated bill of sale), specification of defect(s), transportation prepaid, to the Company at the address shown below.

# Warranty information

VOXX Accessories Corporation (the Company) warrants to the original retail purchaser of this product that should this product or any part thereof, under defective in material or workmanship

normal use and conditions, be proven within 12 months from the date of original purchase, such defect(s) will be repaired or replaced with reconditioned product (at the Company's option) without charge for parts and repair

### static or noise to correction of antenna problems, loss/interruptions of broadcast or internet service, to costs incurred for installation, removal or reinstallation of product, to corruptions caused by computer viruses, spyware or other malware, to loss of media, files, data or content, or to damage to tapes, discs, removable memory devices or

This Warranty does not extend to the

elimination of externally generated

players, home networks or vehicle electrical systems. This Warranty does not apply to any product or part thereof which in the opinion of the Company, has suffered or been damaged through alteration, improper installation, mishandling misuse, neglect, accident, or by removal

cards, speakers, accessories, computers,

computer peripherals, other media

or defacement of the factory serial number/bar code label(s). THE EXTENT OF THE COMPANY'S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT PROVIDED ABOVE AND, IN NO EVENT, SHALL THE COMPANY'S LIABILITY EXCEED THE PURCHASE PRICE PAID BY PURCHASER FOR THE PRODUCT.

This Warranty is in lieu of all other express warranties or liabilities, ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY ANY ACTION FOR BREACH OF ANY WARRANTY HEREUNDER INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY MUST BE **BROUGHT WITHIN A PERIOD OF 24** MONTHS FROM DATE OF ORIGINAL PURCHASE. IN NO CASE SHALL THE

### COMPANY BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY. No person or representative is authorized to assume for the Company any liability other than expressed herein in connection with the sale of this product.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damage so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights and you may also have other rights which vary from state to

### Recommendations before returning your product for a warranty claim:

Properly pack your unit. Include any remotes, memory cards, cables, etc. which were originally provided with the product, However DO NOT return any removable batteries, even if batteries were included with the original purchase. We recommend using the original carton and packing materials. Ship to the address shown below.

Note that product will be returned with factory default settings Consumer will be responsible to restore any personal preference settings. Audiovox Return Centre

Attn: Service Department 150 Marcus Blvd. Hauppauge N.Y. 11788

1-800-645-4994

# **Regulatory Information**

and found to comply with the limits

for a Class B digital device, pursuant

to Part 15 of FCC Rules. These limits

in a residential installation. This

However, there is no guarantee

that interference will not occur in a

does cause harmful interference to

can be determined by turning the

equipment off and on, the user is

encouraged to try to correct the

radio or television reception, which

particular installation. If this equipment

are designed to provide reasonable

equipment generates, uses, and can

not installed and used in accordance

radiate radio frequency energy and, if

with the instructions, may cause harmful

interference to radio communications.

protection against harmful interference

### FCC Information Note: This equipment has been tested

following measures: Reorient or relocate the receiving

connected

Increase the separation between the

interference by one or more of the

- equipment and receiver Connect the equipment into an outlet on a circuit different from that to which the receiver is
- Consult the dealer or an experienced radio/TV technician for Changes or modifications not expressly

approved by VOXX Accessories Corporation could void the user's authority to operate the equipment.

### (5) Skip reverse Press and hold to rewind within the current track

### Play/Pause button Press to pause or resume audio

### Pair button Press and hold for 3 seconds to activate pairing mode. If the speaker is already connected and you would like to connect to a

+ / - button Press to adjust volume on the

### adjust the volume on your device

## On/Off switch